

PRODUCT DESCRIPTION

Stonchem 577 is a high-performance, epoxy hybrid lining system applied at a nominal thickness of 120 mil/3 mm. The mortar, engineering fabric, mineral composite topcoat sequencing provides a chemical barrier for resistance to occasional rubber wheels and foot traffic, thermal shock, thermal cycling, static cracks and permeation. The Stonchem 577 system has excellent resistance to caustics and moderate concentrations of acids.

USES, APPLICATIONS

- Secondary containment areas
- Tank farms
- Sumps and trenches
- Pump pads and pedestals
- Neutralization pits
- Process floors

PRODUCT ADVANTAGES

- Excellent chemical resistance to caustics and moderate concentrations of acids
- Engineering fabric aids in crack resistance
- Mineral composite topcoat for increased impermeability
- Factory proportioned units for easy application

CHEMICAL RESISTANCE

Stonchem 577 is formulated to resist a variety of chemical solutions. (Refer to the Stonchem 500 Series Chemical Resistance Guide for lists of reagent concentrations and temperature recommendations.)

PACKAGING

Stonchem 577 is packaged in units for easy handling. A unit of Stonchem 577 consists of:

Mortar

- 1 carton of Stonchem 500 Series Liquids A carton contains:
 - 4 foil bags of Amine
 - 4 poly bags of Resin
- 4 bags of Mortar Aggregate

Engineering Fabric

- 1 roll of Engineering Fabric 200 sq. ft./18.58 sq. m roll

Saturant

- 0.5 carton of Stonchem 500 Series Liquids
- A carton contains:
 - 4 foil bags of Amine
 - 4 poly bags of Resin

Topcoat

- 1 carton of Stonchem 500 Series Topcoat
- A carton contains:
 - 4 foil bags of Amine
 - 4 poly bags of Resin

COVERAGE

Each unit of Stonchem 577 will cover approximately 180 sq. ft./16.72 sq. m at an application thickness of 120 mil/3 mm.

Note: Coverage rates shown are theoretical. Actual coverage rates may vary. Make necessary allowances for the condition of the surface to be coated, working conditions, waste, spillage, experience level and skill of the installers, etc.

STORAGE CONDITIONS

Store all components between 50 to 75°F/10 to 24°C in a dry area. Keep out of direct sunlight. When stored in the unopened containers at the proper temperatures, the shelf life is 3 years. Store all engineering fabric in a clean and dry area.

PHYSICAL CHARACTERISTICS

Compressive Strength	10,000 psi (ASTM C-579)
Tensile Strength.....	8,700 psi (ASTM D-638)
Flexural Strength	12,750 psi (ASTM C-580)
Flexural Modulus of Elasticity	1 X 10 ⁶ psi (ASTM C-580)
Hardness	85-90 (ASTM D-2240, Shore D)
Abrasion Resistance	0.12 gm max. weight loss (ASTM D-4060, CS-17)
Thermal Coefficient of Linear Expansion	1.2 x 10 ⁻⁵ in./in.°F (ASTM C-531)
Color	Gray
Cure Rate	4 to 6 hours tack-free (@70F°/21°C).....
VOC	24 hours chemical service
	Stonchem 500 Topcoat 55 g/l (ASTM D-2369, Method E) .. Stonchem 500 Liquids 45 g/l

Note: The above physical properties were measured in accordance with the referenced standards. Samples of the actual system, including binder and filler, were used as test specimens.

SUBSTRATE

Stonchem 577, with appropriate primer, is suitable for application over concrete and the following uncoated newly applied Stonhard mortars and grouts: GS, HT, UR, UT, TG6, TG8, CR5 and PM5. For questions regarding other possible substrates or an appropriate primer, contact your local Stonhard representative or Technical Service.

SUBSTRATE PREPARATION

Proper preparation is critical to ensure an adequate bond and system performance. The substrate must be dry and properly prepared utilizing mechanical methods. Questions regarding substrate preparation should be directed to your local Stonhard representative or Technical Service.

APPLICATION GUIDELINES

For optimal working conditions, substrate temperature must be between 60 to 80°F/15 to 27°C. Cold areas must be heated until the slab temperature is above 55°F/13°C to ensure the material achieves a proper cure. A cold substrate will make the material stiff and difficult to apply. Warm areas or areas in direct sunlight must be shaded or arrangements made to work during evenings or at night. A warm substrate (60 to 80°F/15 to 27°C) will aid in the material's workability; however, a hot substrate (80 to 100°F/27 to 37°C) or a substrate directly in the sun will shorten the material's working time and can cause other phenomenon such as pinholing and bubbling. Substrate temperature must be greater than 5°F/3°C above dew point during application and curing period.

Application and curing times are dependent upon ambient and surface conditions. Consult Stonhard's Technical Service Department if conditions are not within recommended guidelines.

PRIMING

Vacuum the surface before priming and make sure the substrate is dry. The use of Stonchem Epoxy Primer is necessary in all applications of Stonchem 577. This ensures maximum product performance. (See Stonchem Epoxy Primer product data sheet for details.)

Note: The Stonchem Epoxy Primer must remain tacky during installation of the mortar.

APPLYING

Mortar

Mix the amine and resin in a 5 gallon mixing bucket on a J.B. Blender for one minute. Next, gradually add the Mortar aggregate while mixing for an additional 150 seconds. Mixing is complete when no clumps of dry material exist. For vertical applications use Vertical Mortar aggregate. Apply the mortar onto the substrate with a 3/8 in. x 3/8 in. V-notched trowel. To obtain the proper thickness, hold the trowel at approximately 45 degrees and keep the tips of the V-notches in contact with the substrate. The material must be applied evenly over the substrate with no clumps or ridges present before embedding the engineering fabric. The engineering fabric will not remove or hide any unevenness in the troweled mortar layer. If applying mortar on a vertical surface, use the same V-notched trowel to spread the material, then finish smooth with a flat steel finishing trowel. A smooth and even distribution of the material must exist on a vertical surface before embedding the engineering fabric.

Engineering Fabric

Place the engineering fabric on the mortar immediately after the mortar is applied. Press the fabric onto the mortar using a dry, medium nap roller. Overlap adjacent engineering fabric 1/2 in./13mm. Immediately apply the saturant.

Saturant

Mix the amine and resin in a 5 gallon mixing container using a heavy-duty, slow-speed drill (400 to 500 rpm) with a Jiffy Mixer for one minute. Apply the saturant to the engineering fabric with a saturated medium nap roller. To wet the roller, dip it into the mixing bucket. Always work from the bucket. Do not pour the saturant directly onto the engineering fabric; this will decrease the saturant's coverage.

Note: If working in warmer conditions, the use of plastic mixing buckets will increase the pot life of the material.

The engineering fabric is completely saturated when white strands are no longer present. When the engineering fabric is completely saturated, roll with a ribbed roller to release air pockets in the reinforcement and to embed the fabric into the mortar. To saturate the overlaps, roll several times over the length of the overlap with a saturated roller, then roll with a ribbed roller several times until the overlap is no longer visible. Allow the mortar, fabric and saturant to cure (approximately 4 to 6 hours) before proceeding.

Topcoat

Lightly sand the saturant and engineering fabric in areas where protrusions exist. Vacuum the area completely. Mix the amine and resin in a 5 gallon mixing container using a heavy-duty, slow-speed drill (400 to 500 rpm) with a Jiffy Mixer for 2 minutes. Pour the material onto the floor and spread out with a 15 mil notched squeegee. Backroll the area with a medium nap roller to remove squeegee lines, using long roll strokes to decrease the visibility of roller lines. For vertical surfaces, pour a bead of material along the base of the wall and, using a medium nap roller, roll the material onto the vertical surface. The wet film thickness of the coating is 10 to 12 mil/250 to 300 microns. Check the thickness with a wet film gauge.

CURING

The surface of Stonchem 577 will be tack-free in 4 to 6 hours at 70°F/21°C. The coated area may be put back in service in 24 hours at 70°F/21°C. Ultimate physical characteristics will be achieved in 7 days.

PRECAUTIONS

- Avoid contact with Stonchem 500 amine and resin, as they may cause skin, respiratory and eye irritation.
- Acetone is recommended for cleanup of Stonchem 500 amine and resin material spills. Use this material only in strict accordance with the manufacturer's recommended safety procedures. Dispose of waste materials in accordance with government regulations.
- The use of NIOSH/MSHA approved respirators using an organic vapor/acid gas cartridge is recommended.
- The selection of proper protective clothing and equipment will significantly reduce the risk of injury. Body covering apparel, safety goggles and impermeable nitrile gloves are highly recommended.
- In case of contact, flush the area with copious amounts of water for 15 minutes and seek medical attention. Wash skin with soap and water.
- If material is ingested, immediately contact a physician. DO NOT INDUCE VOMITING.
- Use only with adequate ventilation.

NOTES

- Safety Data Sheets for Stonchem 577 are available online at www.stonhard.com under Products or upon request.
- Specific information regarding chemical resistance is available in the Stonchem 500 Series Chemical Resistance Guide.
- A staff of technical service engineers is available to assist with product application or to answer questions related to Stonhard products.
- Requests for technical literature or service can be made through local sales representatives and offices, or corporate offices located worldwide.
- The appearance of all floor, wall and lining systems will change over time due to normal wear, abrasion, traffic and cleaning. Generally, high-gloss coatings are subject to a reduction in gloss, while matte-finish coatings can increase in gloss level under normal operating conditions.
- Surface texture of resinous flooring surfaces can change over time as a result of wear and surface contaminants. Surfaces should be cleaned regularly and deep cleaned periodically to ensure no contaminant buildup occurs. Surfaces should be periodically inspected to ensure they are performing as expected and may require traction-enhancing maintenance to ensure they continue to meet expectations for the particular area and conditions of use.

IMPORTANT:

Stonhard believes the information contained here to be true and accurate as of the date of publication. Stonhard makes no warranty, expressed or implied, based on this literature and assumes no responsibility for consequential or incidental damages in the use of the systems described, including any warranty of merchantability or fitness. Information contained here is for evaluation only. We further reserve the right to modify and change products or literature at any time and without prior notice.

06/19

© 2019 Stonhard www.stonhard.com

STONHARD®

USA HQ	(800) 257 7953	Mexico	+(52) 55 9140 4500	Belgium	+(32) 67 49 37 10	South Africa	+(27) 11 254 5500	Australia	+(61) 3 9587 7433
Canada	(800) 263 3112	Argentina	+(54) 11 5032 3113	Dubai, UAE	+(971) 4 3470460	China	+(86) 21 61838698	India	+(91) 22 28500321